

STABILITY AND LOCATION:

- Fountain must be installed and located on a level, smooth and flat surface for proper stability and function.
- Fountain and its components are designed for INDOOR use only.
- Fountain should NOT be used in temperatures near or below freezing.
- It is recommended that this Fountain NOT be placed in a recreational or play area. Damage to the Fountain and/or personal injury could result if children/persons are permitted to climb, play, or lean on this clock.

CAUTION:

- Slippery floor conditions may occur if the Fountain water splashes the surrounding area. See the Troubleshooting Section to adjust the Pump water flow speed.

WARNING: Electric Shock Hazard-

- Keep electrical cords away from high temperature heat sources.
- Ensure excess power cords are stowed to avoid tripping.
- Use 110V AC electrical outlet with Ground Fault Interrupt (GFI) receptacle. Follow all local electrical codes.
- Keep transformer socket and plug off the floor and away from where it could get wet from water.


STEP 1: Unpack

TOOLS REQUIRED FOR ASSEMBLY: (not included)

- 1 - SCREW DRIVER - Slotted
- 1 - SCREW DRIVER - Phillips
- 1 - LEVEL


PARTS LIST: (included)

- | | |
|------------------|---|
| 1 - Wall Section | 1 - Pendulum |
| 1 - Basin | 1 - Dial |
| 1 - Pump | 1 - Movement Cover |
| 1 - Spotlight | 1 - Bag of River Rocks |
| 1 - Transformer | 5 - Spare light bulbs (for Spotlight) |
| 2 - Anchor Bolts | 2 - Brass Pegs with rubber stopper on one end |
| 1 - Light Cup | 1 - Brass Rod without rubber stopper |




STEP 2: Connect Pump

- Set Wall Section on a flat surface, face down.
 - Locate the end of the Water Hose, on the bottom of the Wall Section.
 - Attach the Pump to the Water Hose. Verify the Hose is pushed all the way onto the pump.
- DO NOT PLUG INTO 110V AC ELECTRICAL OUTLET AT THIS TIME.




STEP 3: Basin and Spotlight

- Place the Basin on a flat surface where the fountain will be located. (near two electrical outlets.)
- Level the Basin using the Floor Levelers on the bottom of the Basin.
- Place the Spotlight in the bottom of the Basin at the front center.
- Route the Spotlight power cord out of the Basin through the slot at the back edge. Leave 6-8 inches of extra power cord in the Basin with the Spotlight.




STEP 4: Wall Section to Basin

- (two people recommended)
- Carefully lift the Wall Section and the attached Pump over the Basin. (One person to hold the Wall Section, one person to hold the Pump.)
 - Put the Pump into the center of the Basin.
 - Route the Pump power cord out of the Basin through the slot at the back edge.
 - Lower the Wall Section onto the supports in the Basin so that the holes in the Mounting Plate align with the holes in the Basin Supports.
 - Thread the Anchor bolts through the holes in the Wall Section Mounting Plate and into the Basin supports.
 - Tighten the Anchor bolts with screw driver.
 - Verify the Wall Section is level by adjusting the Levelers. (see Step 3)
- NOTE: Do NOT push on the Wall Section to access the Floor Levelers or move the unit. Lift from the Basin to adjust the Floor Levelers.



STEP 5: Position the Spotlight


- Locate the Light Cup.
- Lift the Spotlight from inside the Basin (see Step 3) and position into the Light Cup.
- Place the Light Cup into position in the Wall Section Mounting Plate as shown.



STEP 6: Spotlight to Transformer


- Connect the plug at the end of the Spotlight cord into the socket on the Transformer.
- Verify that neither the Transformer nor the connection between the Transformer and Spotlight cord are in the Basin where they could get wet.
- Do NOT allow the socket and plug connection between the Spotlight and the Transformer to get in contact with the ground where contact with water could cause electrical shock.

DO NOT PLUG INTO 110V AC ELECTRICAL OUTLET AT THIS TIME.




STEP 7: Add water

- Fill the Basin with clean water, up to underside of Mounting Plate, so that the **pump is completely submerged in the water.** (Distilled, bottled or spring water are recommended. Do not use hot water.)
- NOTE: Only the Pump, the electrical cord directly connected to the Pump, and the Spotlight cord are to come in contact with water. **Under no circumstances should the Transformer, the connection between the Spotlight cord plug and the Transformer socket or other parts come into contact with water.**
- Due to natural evaporation, check water level **DAILY.** Pump must be submerged to operate properly.
- NOTE: Typically the Fountain will require water added every one to two days.
- Place River Rocks on the Wall Section Mounting Plate.



STEP 8: Clock Instructions

- Install the batteries according to the +/- symbols.
- Set the time using the Time Setting Knob.
- Position the Movement Cover over the Movement to keep water from the Fountain off the Movement.




BATTERY REPLACEMENT:

If the clock begins to lose time, or the pendulum swing begins to slow, it is the sign of weak or exhausted batteries. Replace battery with a fresh "AA" Alkaline battery. **IMPORTANT:** Never leave an exhausted battery in your clock as it could leak and damage your clock.

STEP 9: Dial and Pendulum

- Screw the Brass Pegs with rubber stoppers into the bottom two holes of the Wall Section, as shown below.
- Screw the Brass Rod without the rubber stopper into the top hole of the Wall Section, as shown below.
- NOTE: Some threads will remain exposed on the Pegs and Rods.
- Slide the Dial Mounting Sleeve over the Brass Rod near the top of the Wall Section until the back of the Dial rests against the Brass Pegs.
- Align the Dial so that it hangs straight and level.
- Tighten the Set Screw on the Dial Mounting Sleeve.
- Hang the Pendulum onto the Pendulum Hanger (see Step 8)
- Start the Pendulum swing by gently moving the Pendulum to the left or right side of the Fountain and release. The pendulum will settle into an even swinging motion after a few minutes.




STEP 10: Start Fountain

- Verify that the water level allows the Pump to be completely submerged in the water.
- Plug Pump power cord and Transformer into **110V AC electrical outlet with GFI receptacle.** Do NOT plug-in or use this product if any part of it appears to be damaged or operates abnormally. Have the product examined and repaired, if necessary, by a qualified electrician.
- Pump will begin to fill the Reservoir at the top of the Fountain Wall Section. Pump **MUST** first fill the Reservoir at the top of the Fountain before water can begin to flow out of Fountain. This could take up to a minute for the water to begin flowing. If there is still no water flow after a minute, you will need to prime the Pump.
- Adjust the Spotlight so that it shines on the Fountain as desired.

PRIMING THE PUMP:

- Plug the Pump power cord into 110AC electrical outlet for 1-2 minutes. If water does not flow out of the top of the Fountain, unplug the power cord.
 - Repeat above step as necessary to cycle the Pump
- This "Priming" action is normal and is generally not necessary after initial installation. **DO NOT** let the Pump operate when not fully submerged in water. Doing so may damage the Pump. Always submerge the Pump in water, and then plug in the power cord.
- NOTE:** If water flows out of the top of the unit unevenly, see the Troubleshooting section.



TROUBLE SHOOTING:

Clean the Fountain periodically with a damp cloth to prevent mineral deposits and algae. In order to avoid build up of algae, it is strongly recommended that the Pump and Basin be rinsed and cleaned with either vinegar or specially formulated solution.

If debris is caught in the intake vents of the Pump, disconnect the Pump from the power source and rinse the Pump under clean water.

If the fountain will not be used for an extended time, disconnect power and empty the Basin.


WARNING: To help prevent electric shock, use only the AC Adapter provided with the Fountain. Do not allow the clock movement to get wet. Keep the Fountain away from radiators, heat sources, direct sun light, and extreme temperatures. Ensure that the electrical cord is not located where it can be tripped over or get wet. Take care to ensure excess power cords are stowed to avoid tripping.

Fountain Face is made from real slate. Each piece of slate has its own distinctive pattern of colors, shades, and texture. Because of these unique variations, no two fountain faces will be the same. Slate can flake off during the shipment process and should be considered normal. Contact a stone specialist regarding specific care and questions you might have regarding stone surface care.

Parts of the Fountain contain copper. Copper will age and change colors over time. Use cleaning, polishing and care products that are specifically designed for use on copper.

Moving Fountain:

- Disassemble, empty, and then move.
- Do NOT push on the Wall Section while it is attached to the Basin to move clock.
- Disassemble Wall Section from Basin, then relocate the Basin and follow these instructions to assemble and start the Fountain again.



Pump operates, but there is no water flow.:


- Check 110V AC power source.
- Ensure that the power cord is properly plugged into a 110V AC electrical outlet.
- Make sure the Pump is fully submerged in water. (Step 7)
- Check Water Hose is connected to the Pump and Reservoir.
- Verify water level (Step 7)
- Ensure that the Fountain is on a flat smooth surface.
- Prime the Pump. (Step 10)
- Check that there is not a pinch in the water hose.

Noise from fountain:

- Check water level and make sure the pump is fully submerged in water.
- Do not let the pump run when not fully submerged in water. Doing so for an extended period of time may damage the Pump and is not covered under warranty.

Pump water flow speed :

- Water flow speed is factory preset. To change the speed, adjust using the control located on the Pump housing.
- Water splashing can be controlled by adjusting the water flow setting.



Dry Spots or uneven water flow (water flow all to the left or right):

- Adjust floor levelers. (Do Not push on Wall Section while it is attached to the Basin to move, tilt, or level Fountain. Lift Basin to adjust the Floor Levelers.)
- Wipe wet finger/hand across dry spots on slate to disperse water flow over the slate's irregular surface. (water follows path of least resistance)

Spotlight will not go on:

- Unplug Spotlight power cord from 110 AC electric supply.
- Check light bulb and make sure it is connected to socket.
- Check plugs.
- Install new bulb as necessary.

Changing the Light Bulb:

Bulb: low voltage (12V) halogen bulb. (MR-11 Max 10W)

- Unplug Spotlight power cord from 110 AC electric supply.
- Twist cover cap counter clockwise to remove lens.
- Unplug the Light Bulb.
- Plug a new Light Bulb into socket and twist the lens and cover cap clockwise to seal the bulb.
- Replacement bulbs are not covered under warranty.

GARANTIA LIMITADA

Este producto fue fabricado utilizando únicamente los mejores materiales, y ha sido probado y examinado minuciosamente antes de salir de nuestra fábrica.

Howard Miller le garantiza al consumidor/comprador original, o recipiente de este producto, que este reloj estará libre de defectos en material y fabricación bajo uso y servicio normal, por un período de uno año a partir de la fecha de compra. La obligación de Howard Miller bajo esta garantía se limitará a la reparación de este producto utilizando componentes nuevos o renovados, o, as su opción, cambiará este producto con uno nuevo o renovado. Esta garantía no incluye daños al producto o sus componentes que son el resultado de abuso, accidentes, alteraciones, condiciones climatológicas o de medio ambiente, mal uso o reparaciones no autorizadas. Esta garantía es nula si existe cualquier daño, o algún daño ocasionado en exceso de uso normal, daños por motivo del trar servicio efectuado por una persona no autorizada o se vende por cualquier persona que no sea un distribuidor autorizado de Howard Miller. El reemplazo de los focos no está cubierto por la garantía. El daño de la bomba ocasionado por su funcionamiento al no estar totalmente sumergida en el agua NO está cubierto por la garantía.

HOWARD MILLER RENUNCIA A CUALQUIER RESPONSABILIDAD POR DAÑOS INCIDENTALES O CONSECUENTES COMO RESULTADO DE UNA VIOLACION DE ESTA GARANTIA U OTRA GARANTIA IMPLICITA. GARANTIAS IMPLICITAS PARA ESTE PRODUCTO REGIRAN UNICAMENTE DURANTE LA DURACION DE LA GARANTIA DESCRITA ARRIBA, Y DESPUES, NO HABRAN GARANTIAS IMPLICITAS O EXPLICITAS (INCLUYENDO LA APTITUD O CONVENIENCIA PARA UN PROPOSITO EN PARTICULAR) EN ESTE PRODUCTO.

Algunos estados no permiten limitaciones en cuanto a la duración de una garantía implícita, o de daños incidentales o consecuentes; por lo tanto, es posible que la limitación anterior lo excluya a Ud. Esta garantía le ofrece derechos legales específicos, y es posible que Ud. cuente también con otros derechos que varían de estado a estado.

GARANTIE LIMITÉE

Ce produit a été fabriqué en utilisant uniquement les meilleures matières et a fait l'objet d'essais approfondis avant de quitter l'usine.

Howard Miller garantit au consommateur ou à l'acheteur original, ou à la personne recevant ce produit qu'il ne comporte aucun vice de matériel ou de confection pendant une période de une année à compter de la date d'achat lorsqu'il fait l'objet d'une utilisation et d'un entretien normaux. L'obligation de Howard Miller aux termes de la présente garantie est limitée à la réparation du produit avec des composants neufs ou remis à neuf ou, à sa seule discrétion, à son remplacement par un produit neuf ou remis à neuf. Cette garantie ne couvre pas les dommages subis par le produit ou ses composants à la suite d'abus, d'accident, d'altération, d'exposition aux mauvaises conditions climatiques ou environnementales, ni les dommages excédant l'usage normale, ceux causés en cours d'expédition ou par suite d'une mauvaise manutention, d'une utilisation incorrecte ou d'une réparation non autorisée. Cette garantie est annulée si un travail est effectué par une personne non autorisée ou si le produit est vendu par une personne autre qu'un concessionnaire Howard Miller agréé.

Les ampoules de rechange ne sont pas couvertes par la garantie. Les dommages à la pompe découlant du fonctionnement de la pompe non entièrement immergée dans l'eau NE sont PAS couverts par la garantie.

HOWARD MILLER NIE TOUTE RESPONSABILITÉ EN MATIÈRE DE DOMMAGES INDIRECTS OU CONSÉCUTIFS RÉSULTANT DU NON RESPECT DE LA PRÉSENTE GARANTIE OU DE TOUTES GARANTIES IMPLICITES. CES DERNIÈRES NE SONT EN VIGUEUR QUE PENDANT LA DURÉE DE LA GARANTIE EXPRESSE ÉNONCÉE CI-DESSUS. PAR LA SUITE, LE PRODUIT N'EST COUVERT PAR AUCUNE GARANTIE EXPRESSE OU IMPLICITE (Y COMPRIS LA GARANTIE DE VALEUR MARCHANDE ET DE CONFORMITÉ À UN USAGE PARTICULIER).

Certains états ne permettent pas l'exclusion ou la limitation des dommages indirects ou consécutifs, ou la limitation de durée d'une garantie implicite. Par conséquent, il est possible que les limitations et exclusions édictées ci-dessus ne vous concernent pas. Cette garantie vous accorde des droits spécifiques. Vous pouvez également bénéficier d'autres droits variant d'un état à l'autre.

BESCHRÄNKTE GARANTIE

Dieses Produkt ist nur aus den feinsten Materialien hergestellt und ist vor dem Verlassen unserer Fabrik gründlich getestet worden.

Howard Miller garantiert dem ursprünglichen Verbraucher/Käufer oder Empfänger, dass dieses Produkt bei normaler Benutzung und normalem Service für ein Jahr ab Kaufdatum frei von Material- und Verarbeitungsfehlern ist. Howard Millers Verbindlichkeit unter dieser Garantie ist auf die Reparatur des Produkts mit neuen oder reparierten Komponenten beschränkt. Das Produkt kann nach dem Ermessen von Howard Miller mit einem neuen oder reparierten Produkt ersetzt werden. Diese Garantie schließt keine Schäden an dem Produkt oder Teilen des Produkts ein, die eine Folge von Mißhandlung, Unfall, Änderung, klimatischen oder umgebungsbedingten Umständen, den normalen Gebrauch überschreitenden Schäden, Frachtschäden, fehlerhafter Handhabung, Mißbrauch und nichtgenehmigter Reparatur sind. Diese Garantie erlischt, wenn jegliche Reparaturarbeiten durch eine unberechtigte Person durchgeführt oder die Uhr durch einen nicht autorisierten Howard Miller-Vertragshändler verkauft wurde.

Die Garantie erstreckt sich nicht auf Ersatzglühlampen. Beschädigungen, die beim Betrieb der nicht vollständig im Wasser eingetauchten Pumpe entstehen, werden durch die Garantie NICHT abgedeckt.

HOWARD MILLER LEHNT JEDE HAFTUNG FÜR DIREKTE ODER INDIREKTE SCHÄDEN AB, DIE AUS EINER VERLETZUNG DIESER GARANTIE ODER GESETZLICHEN GEWÄHRLEISTUNG ENTSTEHEN. GESETZLICHE GEWÄHRLEISTUNGEN FÜR DIESES PRODUKT GELTEN NUR FÜR DIE DAUER DIESER OBEN ANGEGBENEN AUSDRÜCKLICHEN GARANTIE, WORAUF FÜR DIESES PRODUKT KEINE WEITEREN GARANTIE, WEDER AUSDRÜCKLICHE NOCH MUTMASSLICHE (EINSCHLIESSLICH HANDELSÜBLICHE QUALITÄT ODER EIGNUNG FÜR EINEN BESTIMMTEN ZWECK) GEWÄHRT WERDEN.

In manchen Staaten ist die Ausnahme oder Beschränkung von direkten oder indirekten Schäden oder die Begrenzung für die Geltungsdauer einer Gewährleistung unzulässig. Deshalb ist es möglich, daß die obigen Begrenzungen und Ausnahmen nicht auf Sie zutreffen. Diese Garantie gewährt Ihnen spezifische gesetzliche Rechte und kann andere Rechte mit einschließen, die von Staat zu Staat unterschiedlich sind.

INFORMACION DE SERVICIO

Antes de intentar conseguir servicio, asegúrese de que todas las instrucciones incluidas aquí hayan sido cuidadosamente efectuadas. Estas instrucciones le ofrecerán información detallada, la cual contestará a la mayoría de sus preguntas. La mayoría de los problemas se pueden resolver sin devolver el reloj para servicio. (www.howardmiller.com)

Antes de llamar, favor de tener disponible la siguiente información. Puede encontrar el número de modelo y número de serie en la etiqueta de información de producto.

En el caso poco probable de que su reloj requiera reparaciones, en **NORTE AMERICA** favor de llamar a alguno de nuestros técnicos en reparaciones, al (616) 772-7277 (extensión #386). **FUERA DE NORTE AMERICA**, favor de llamar a nuestro distribuidor o agente.

Número de modelo: _____ Número de serie: _____

Fecha de compra: _____ Lugar de compra: _____

Breve descripción del problema: _____

- Contacte al departamento de servicio al cliente de Howard Miller.
- Mantenga a mano una copia de la factura original, u otro documento que confirme la compra del reloj.
- Tenga a mano el número de modelo y número de serie y una completa descripción del problema..
- Se requiere autorización previa para devolver cualquier producto o componente a Howard Miller.

Se le cobrará por el servicio: (a) en caso de no presentar una factura u otra documentación, (b) en caso de seguir las instrucciones, (c) si se encuentra vencida la garantía, o (d) si por alguna otra razón queda fuera del ámbito de la Garantía Limitada. Los cargos de transporte a y desde la ubicación de servicio deben ser pagados por el comprador.

Es la responsabilidad del consignatario reclamar daños directamente al el transportista. Si la caja tiene "daños visibles", pídale al chofer que anote el daño en la factura. Si la caja no tiene algún daño visible, pero el reloj fué dañado durante el transporte, notifique al transportista y pídale que dentro de 14 días se realice una inspección y reporte de daño.

SERVICE

Avant de communiquer avec le service à la clientèle, assurez-vous d'avoir suivi attentivement toutes les instructions fournies avec votre horloge Howard Miller. Ces dernières répondent en détail à la plupart des questions. Communiquez avec le site Internet de Howard Miller pour obtenir une liste des questions fréquemment posées, qui pourrait vous permettre de résoudre votre problème ou répondre à votre question de façon pratique." (www.howardmiller.com)

Dans l'éventualité où votre horloge fonctionnerait mal ou devrait être réparée, en **AMÉRIQUE DU NORD**, composez le (616) 772-7277 (poste 386) pour parler à un de nos techniciens du service des réparations. **AILLEURS**, appelez votre distributeur ou votre agent.

Veillez avoir ces instructions disponibles au moment de l'appel. Avant d'appeler, veuillez obtenir les renseignements suivants. Les numéros de modèle et de série se trouvent sur l'étiquette de renseignements sur le produit.

Numéro de modèle : _____ Numéro de série : _____

Date d'achat : _____ Nom du magasin : _____

Breve description du problème : _____

- Communiquez avec le service à la clientèle de Howard Miller.
- Fournissez une copie de la facture originale ou toute autre preuve d'achat ou de la date de réception.
- Indiquez les numéros de modèle et de série et une description complète du problème.
- Une autorisation de retour de marchandise doit être obtenue du service à la clientèle de Howard Miller avant de retourner tout produit ou pièce.

Vous devrez acquitter les frais de réparation si vous ne fournissez pas de facture ou une autre preuve de la date d'achat, si vous n'avez pas suivi les instructions, si la période de validité de la garantie limitée est échue ou si la réparation en excède le cadre.

Le destinataire est responsable de présenter directement au transporteur les réclamations relatives à toute marchandise perdue ou endommagée par ce dernier. Si le carton comporte des «dommages visibles», le destinataire doit indiquer au chauffeur d'en prendre note sur le connaissance. Si le carton contient des «dommages dissimulés», il doit en avvertir le transporteur et lui demander par écrit de procéder à une inspection et de produire un rapport dans une période de 14 jours suivant la réception du produit, au risque de perdre ses droits à la réclamation.

SERVICE-INFORMATIONEN

Ehe Sie einen Reparaturdienst anstreben, vergewissern Sie sich, daß alle Anweisungen, die mit Ihrem Produkt von Howard Miller geliefert wurden, sorgfältig befolgt worden sind. Diese Anweisungen geben Ihnen genaue Information für die Beantwortung der meisten Fragen. Besuchen Sie die Howard Miller Website für eine Liste mit häufig gestellten Fragen. Mit diesen Informationen können Sie ggf. Ihr Problem beheben, oder Antworten auf Ihre Fragen erhalten. (www.howardmiller.com)

Indem unwahrscheinlichen Fall, daß Ihre Uhr nicht richtig zu funktionieren scheint und Reparatur benötigt, rufen Sie bitte in **NORDAMERIKA** einen unserer Reparaturfachleute unter +1-616-772-7277 (Apparat 386) an. **AUSSERHALB VON AMERIKA** rufen Sie bitte Ihren Händler oder Vertreter an.

Ehe Sie anrufen, halten Sie bitte die folgende Informationen bereit. Die Modell- und Seriennummern befinden sich auf dem Produktinformationsetikett. Bitte halten Sie auch diese Anweisungen bereit, wenn Sie anrufen.

Modellnummer: _____ Seriennummer: _____

Kaufdatum: _____ Kaufort: _____

Kurze Beschreibung des Problems: _____

- Setzen Sie sich mit der Kundendienstabteilung von Howard Miller in Verbindung.
- Sie müssen über den Original-Kaufbeleg oder anderem Beweis über den Kauf oder das Erhaltdatum verfügen.
- Geben Sie die Howard Miller Modell- und Seriennummer, sowie eine komplette Beschreibung des Problems an.

4. Vor Rückgabe aller Produkte oder Teile an Howard Miller ist eine Rückgabegenehmigung von dem Howard Miller Kundendienst erforderlich.

Reparaturdienste werden Ihnen berechnet, wenn kein Rechnungsbeleg oder Kaufdatumsbeweis vorliegt, wenn Anweisungen nicht befolgt wurden, wenn das Produkt außerhalb des Garantiezeitraums liegt oder sich auf andere Weise außerhalb des Bereichs der Garantie befindet. Die Transportkosten von und zum Ort der Reparatur trägt der Käufer.

Die folgenden geringfügigen Leistungen sind nicht unter dieser Garantie gedeckt. Reparaturdienst und/oder Teile, um diese Leistungen auszuführen gehen auf Kosten des Verbrauchers.

Der Empfänger ist dafür verantwortlich, alle Frachtverluste oder -schäden direkt an den Spediteur zu melden. Wenn der Karton sichtbare Schäden aufweist, weisen Sie den Fahrer an, den Schaden auf dem Lieferschein zu vermerken. Wenn der Karton "verborgene Schaden" enthält, benachrichtigen Sie den Spediteur und beantragen Sie schriftlich innerhalb von zwei Wochen nach Empfang der Ware eine Spediteurinspektion und einen Schadensbericht. Bei Nichtbenachrichtigung des Spediteurs innerhalb von 2 Wochen nach Empfang der Ware kann es sein, daß Sie möglicherweise auf Schadenersatzansprüche verzichten.

LIMITED WARRANTY:

This product has been manufactured using only the very finest of materials and has been thoroughly tested prior to leaving our manufacturing facility.

Howard Miller warrants to the original consumer/purchaser or recipient that this product will be free from defects in material and workmanship under normal use and service for a period of one year from date of purchase. Howard Miller's obligation under this warranty shall be limited to repairing the product with new or renewed components or, at its option, replacing it with a new or renewed product. This warranty does not include damage to product or components resulting from abuse, accident, alteration, climatic/environmental conditions, damage beyond normal use, freight damage, mishandling, misuse, or unauthorized repair. This warranty is void if any service is performed by an unauthorized person or sold by anyone other than an authorized Howard Miller dealer.

Replacement light bulbs are not covered under warranty. Pump damage caused by operating while not fully submerged in water is NOT covered under warranty.

HOWARD MILLER DISCLAIMS ANY LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF BREACH OF THIS WARRANTY OR ANY IMPLIED WARRANTY. IMPLIED WARRANTIES ON THIS PRODUCT SHALL BE IN EFFECT ONLY FOR THE DURATION OF THE EXPRESS WARRANTY SET FORTH ABOVE AND THEREAFTER, THERE SHALL BE NO WARRANTIES, EXPRESS OR IMPLIED, (INCLUDING MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE), ON THIS PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages or the limitation on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

SERVICE INFORMATION:

Before pursuing service, ensure that all instructions provided with your Howard Miller product have been carefully followed. These instructions will provide detailed information to answer most questions. Contact the Howard Miller web site (www.howardmiller.com) for a list of frequently asked questions that may conveniently resolve your problem or answer your question.

In the unlikely event that your clock appears to be malfunctioning or requires repair, in **NORTH AMERICA** please call one of our Repair Technicians at (616) 772-7277 (extension # 386). **OUTSIDE NORTH AMERICA** please call your distributor or agent.

Before calling, please have the following information available. The model number and serial number can be found on the Product Information Label. Please also have these instructions available at the time of your call.

Model Number: _____ Serial Number: _____

Date Purchase: _____ Where Purchase: _____

Brief Description of Problem: _____

- Contact the Howard Miller Customer Service Department. Phone: (616) 772-7277, Fax: (616) 772-1670, E-mail: customerservice@howardmiller.com
- Have a copy of the original bill of sale or other proof of purchase or receipt date available.
- Have the Howard Miller model number and serial number and a complete description of the problem available.
- Return authorization is required from Howard Miller Customer Service prior to the return of any product or component to Howard Miller.

You will be charged for repair services if a bill of sale or other proof of purchase date is not provided, if instructions were not followed, if the product is beyond the Limited Warranty period or is otherwise outside the scope of the Limited Warranty. Transportation charges to and from the repair location must be paid by the purchaser.

It is the responsibility of the consignee to claim any freight loss or damage directly with the carrier. If the carton indicates signs of "visible damage", instruct the driver to note the damage on the freight bill. If the carton contains "concealed damage", notify the carrier and request in writing within 14 days of product receipt a carrier inspection and damage report. Failure to notify the carrier within 14 days of product receipt may waive your rights to a damage claim.